

Decorative Millwork

TIP: You may wish to paint, stain or faux finish your decorative millwork piece prior to installation. This can speed up installation and reduce errors.

INSTALLATION INSTRUCTIONS

MATERIALS NEEDED



1. MARK INSTALLATION AREA

Select the location for your Decorative Millwork. Hold the millwork in place and mark the location with a pencil.

2. APPLY ADHESIVE

Apply a 1/4" bead of PL Premium Adhesive to only the portion of the millwork surface that will touch the mounting surface.

3. FASTEN MILLWORK INTO PLACE

Press the millwork in place using the pencil marks as guides. Fasten securely with nails or screws. Countersink fasteners and fill holes with caulk or wood filler.

4. FILL GAPS

If desired, caulk around millwork, filling any gaps between millwork and mounting surfaces.

5. FINISH AS DESIRED

Sand or texture any filled holes and touch up with paint or other finishes, as desired.

- Tape Measure
- Hammer or Pneumatic Nailer
- Corrosion-resistant Nails
- Nail Countersink
- Caulk Gun
- PL Premium Adhesive
- Safety Glasses
- Caulk or Wood Filler
- Sandpaper
- Pencil
- Latex or Oil Base Paint

USING CORROSION-RESISTANT FASTENERS AND PL PREMIUM ADHESIVE

Always use corrosion-resistant mechanical fasteners (nails or screws) and PL Premium Adhesive when installing Fypon products. This combination provides a secure, long lasting bond. Countersink all fasteners about 1/8 inch and fill with exterior grade white spackle. If desired, sand any minor imperfections and topcoat with a quality exterior latex or oil base paint. Fypon exterior millwork installations should be finished using a quality, exterior grade silicone caulk to prevent water infiltration behind siding, windows and doors. Some exterior millwork installations, in particular new construction (before siding is applied) may require a J-channel and/or flashing to prevent water infiltration. Installers must determine which installation technique is best for the specific situation.

IMPORTANT:

Please read these installation guidelines thoroughly before beginning installation. Please note that these guidelines are provided only to assist with the installation of Fypon mouldings and millwork products. Modified procedures may be required in order to meet specific situations, unique applications and local building codes. The manufacturer does not under any circumstances warrant the installation of its products. Be sure to wear appropriate protective clothing, gloves and safety glasses when working with any tools. Installer should check for and relocate all electrical wiring within the proposed installation area, as needed (be sure to disconnect all electric power before working with any electrical wiring and follow all applicable local electrical codes and safety procedures).