


Louvers

TIP: You may wish to paint, stain or faux finish your decorative millwork piece prior to installation. This can speed up installation and reduce errors.

INSTALLATION INSTRUCTIONS

MATERIALS NEEDED



Functional Louver



Decorative Louver

Fypon manufactures two types of Louvers - decorative and functional.

Decorative Louvers have closed non-ventilating slats that do not allow air to pass through. They are used for decorative purposes only to accent exterior sidewall applications.

Functional Louvers accent exterior sidewall applications, but also have open slats that allow for air ventilation.

TO INSTALL A FUNCTIONAL LOUVER:

1. Hold the Louver against the siding.
2. Using the Louver as a template, trace the outline of the perimeter of the Louver as it rests against the siding. Check to make sure your cut will not pass through studs and electrical lines.
3. Cut a **2" undersized hole** inside the outline of the Louver.
4. Attach the Louver with corrosion-resistant fasteners and PL Premium adhesive.

TO INSTALL A DECORATIVE LOUVER:

1. Apply PL Premium Adhesive to the perimeter edge of the backside of the Louver.
2. Place the Louver in position against the exterior sidewall of the home, making sure it is level.
3. Secure Louver with non-corrosive fasteners.
4. Wipe off excess adhesive.

Safety Glasses
Tape Measure
Hammer or Pneumatic Nailer
Nail Countersink
Corrosion-resistant Finishing Nails or Screws
Caulk Gun
PL Premium Adhesive
Caulk or Wood Filler
Sandpaper
Pencil
Latex or Oil Base Paint
Ladder
Jig Saw
(for functional Louver installation)

USING CORROSION-RESISTANT FASTENERS AND PL PREMIUM ADHESIVE

Always use corrosion-resistant mechanical fasteners (nails or screws) and PL Premium Adhesive when installing Fypon products. This combination provides a secure, long lasting bond. Countersink all fasteners about 1/8 inch and fill with exterior grade white spackle. If desired, sand any minor imperfections and topcoat with a quality exterior latex or oil base paint. Fypon exterior millwork installations should be finished using a quality, exterior grade silicone caulk to prevent water infiltration behind siding, windows and doors. Some exterior millwork installations, in particular new construction (before siding is applied) may require a J-channel and/or flashing to prevent water infiltration. Installers must determine which installation technique is best for the specific situation.

IMPORTANT:

Please read these installation guidelines thoroughly before beginning installation. Please note that these guidelines are provided only to assist with the installation of Fypon mouldings and millwork products. Modified procedures may be required in order to meet specific situations, unique applications and local building codes. The manufacturer does not under any circumstances warrant the installation of its products. Be sure to wear appropriate protective clothing, gloves and safety glasses when working with any tools. Installer should check for and relocate all electrical wiring within the proposed installation area, as needed (be sure to disconnect all electric power before working with any electrical wiring and follow all applicable local electrical codes and safety procedures).